

PRE - SPACED LEGEND APPLICATION



Follow these Step-by-step instructions below for best legend application.

First make sure the surface of the vehicle or sign is clean and dry. Refer to [OUR DECAL APPLICATION](#) for best practices of surface cleaning and preparation.



GENERAL APPLICATION:

Refer to this for best practices of surface cleaning and preparation.

GENERAL APPLICATION:

- ▶ **STEP ONE:** Lay the premasked legend on a flat smooth surface. Using a 2" or wider roll of masking tape apply across the entire top of the premask with about half being on the legend and the remaining on the smooth surface. It might be helpful on exceptionally long and big legends to apply another strip of masking tape about half being on the existing masking tape. This will make a stronger hinge when applying.
- ▶ **STEP TWO:** Take the legend and carefully affix it to the surface using the masking tape. Press the masking tape firmly to ensure a good adhesion.
- ▶ **STEP THREE:** Lift the bottom of the legend all the way up. Lift the bottom of the legend all the way up. The masking tape is holding the position of the legend in place. Peel the backing paper from the legend starting at top of the legend which is at the point of the masking tape hinge.
- ▶ **STEP THREE:** Slowly allow the legend to fall back into position. Using a plastic application tool [a credit card works great] apply pressure starting in the middle and working to the edges. Once the entire legend has been applied remove the masking tape and the top piece of pre-mask material.